INJ CALCULATOR SENSOR



07/94 M1441010

M1441010

- INJECTION XU10J2, BVM

1	1929 36	01	**INJ CALCULATOR**
2	6555 88	03	**ELECTRIC RELAY** 25 AMP FUEL PUMP INJECTION INLET - COOLING COMPRESSOR
3	1920 C4	01	**SENSOR ENGINE** DIAM 12X150
4	1920 C5	01	**TEMPERAT PROBE**
5	1920 C3	01	**SPEED SENSOR** TO O 06628
	1920 W9	01	FROM O 06628
6	1920 J7	01	**PRESSURE SENSOR**
7	5953 06	01	**VACM UNIT UNION** CL 3,5X8-5000
8	1623 R0	01	**POTENTIOMETER**
30	6936 33	04	**NUT WITH BASE** DIAM 6X100-8-13
31	6925 53	04	**SCREW RLX** DIAM 6X100-20
32	6922 97	01	**SELF-TAP SCREWS** DIAM 6X100-20
33	6912 87	01	**SCREW CBLX RDL** DIAM 4X70-20

INJ CALCULATOR SENSOR





M1441900

13	1622 C9	01	**SENSOR PEDAL** BOSCH
14	5918 C5	01	**SPEED SENSOR** 2 VCIES
15	5518 64	01	**HOUSING**
16	198J 18	01	**INJECTOR-HOLDER**
17	1920 Z1	01	**AIR METRG DEVIC** -EEC 95 DEPOLL (ENGINE)
18	1635 93	01	**CONTROL-UNIT** -EEC 95 DEPOLL (ENGINE)
19	1565 J1	01	**HOG RING** DIAM 8-12
30	5922 97	01	**SELF-TAP SCREWS** DIAM 6X100-20
31	6935 74	01	**WASHER-NUT** 6X100-6,9-10
32	6925 82	02	**SELF-TAP SCREWS** DIAM 5X80-40
33	6936 33	02	**NUT WITH BASE** DIAM 6X100-8-13
34	6943 59	02	**SPEED NUT** 5X90-20,4-14
35	6981 82	02	**HOSE CLIP** DIAM 11-13 LARG 9
36	6917 31	01	**CAPSCREW** DIAM 7X100-16
37	6962 12	01	**FLEXIBLE WASHER** 7X13,7-0,8

31/08/2001

INJ CALCULATOR SENSOR



M1441900

- TURBO DIESEL DK5ATE

1	1929 X9	01	**INJ CALCULATOR** -EEC 19-5 DEPOLL (ENGINE)
	1929 Y0	01	-US 87 DEPOLL (ENGINE)
	1929 CP	01	-EEC 95 DEPOLL (ENGINE)
2	1920 W9	01	**SPEED SENSOR**
3	1929 J8	01	**RELAY** -TO O 00589 - US 87 DEPOLL (ENGINE) OR EEC 19-5 DEPOLL (ENGINE)
	1920 SX	01	- EEC 95 DEPOLL (ENGINE) OR US 87 DEPOLL (ENGINE) FROM O 06570 OR EEC 19-5 DEPOLL (ENGINE) FROM O 06570
4	1920 C5	01	**TEMPERAT PROBE**
5	1920 K9	01	**SENSOR ENGINE** 12X1,50
7	1920 T7	01	**PRESSURE SENSOR** - US 87 DEPOLL (ENGINE) OR EEC 19-5 DEPOLL (ENGINE)
	1920 3L	01	-EEC 95 DEPOLL (ENGINE)
8	0382 79	01	**SENSOR BRACKET** - US 87 DEPOLL (ENGINE) OR EEC 19-5 DEPOLL (ENGINE)
	0382 F8	0.	-EEC 95 DEPOLL (ENGINE) (+ 0382 F8 (01) TO O 07083)
9	1920 V8	01	**UNION**
10	1563 C5	01	**UNION-SCREW** DIAM 12X150-24
11	1933 14	02	**FUEL PIPE SEAL** 12,1X18-2 C002 COPPER
12	1920 V9	01	**UNION** - US 87 DEPOLL (ENGINE) OR EEC 19-5 DEPOLL (ENGINE)
	0382 F9	01	**AIR HOSE** -EEC 95 DEPOLL (ENGINE) (+ 0382 F8 (01) TO O 07083)

.../...

31/08/2001

INJ CALCULATOR SENSOR



M1441750

30	6922 73 01	SELF-TAP SCREWS	DIAM 6X100-12
31	6913 F2 01	SCREW	DIAM 6X100-12

31/08/2001

INJ CALCULATOR SENSOR

- TURBO D ESEL XUD11BTE

A) TINED CONNECTOR
B) GILDED CONNECTOR



M1441750

			INJ CALCULATOR
1	1929 CE	01	-EEC 95 DEPOLL (ENGINE), DVM
	1929 7Y	01	-EEC 2000 DEPOLL (ENGINE), BVM
	1929 6Q	01	-BVA
2	1920 W9	01	**SPEED SENSOR**
3	1920 3X	01	**RELAY**
4	1920 C5	01	**TEMPERAT PROBE**
5	1338 78	01	**SENSOR ENGINE** WE GREEN
6	1920 X0	01	**PRESSURE SENSOR**
			SENSOR PEDAL
7	1622 C9	01	BOSCH -BVM TO O 06892
	1920 X1	01	-BVM FROM O 06893
	1622 F2	01	-BVA
			INJECTOR-HOLDER
8	1980 25	01	SEE A WITH INJECTOR AND SENSOR TO O 07363
	1980 66	01	-EEC 95 DEPOLL (ENGINE) SEE B WITH INJECTOR AND SENSOR FROM O 07364
	1980 29	01	-EEC 2000 DEPOLL (ENGINE) SEE B WITH INJECTOR AND SENSOR
			SPEED SENSOR
10	5918 85	01	2 VOIES 2-PIN CONNECTOR
	6160 24	01	3 VOIES 3-PIN CONNECTOR
11	0157 14	01	**PLUG SEAL** DIAM 12.7X18-1.5
12	1957 68	01	**HOSE PRESSURE**
13	5918 84	01	**HOUSING**

.../...

31/08/2001

INJ CALCULATOR SENSOR



M1441300

- INJECTION ES9J4

1	1929 7J	01	CALCULATOR -BVM
	1929 7K	01	-BVA
2	1920 3X	01	RELAY
3	1920 W9	01	SPEED SENSOR
4	1920 4G	01	TEMPERAT PROBE
5	1628 8V	01	POTENTIOMETER
6	5946 25	01	PINKING SENSOR VE GREEN
7	6555 N7	01	HOG RING 8 (12 -0.7-4
8	6555.68	01	ELECTRIC RELAY 25 AMP VI VIOLET
9	1920 9H	01	PRESSURE SENSOR BOSCH TO 0 08077
	1920 AN	01	FROM 0-08078
10	1338 91	01	SENSOR 12X150
70	6925 C1	01	SCRE WITH BASE DIAM 8X125-35
71	6923 77	02	SET SCREWS DIAM 6X100-16

INJ CALCULATOR SENSOR



33	6935 31		01	*NUT WITH BASE 5X80-4,6-8*
	RP 6936 39		01	
34		6922 97	02	**SELF TAP SCREWS** DIAM 6X100-20
35		6925 56	01	**SCREW WITH BASE** DIAM 6X125-27

INJ CALCULATOR SENSOR



M1441250

- INJECTION ZPJ4

1	1929 1Z	01	**CALCULATOR** -ENGINE REF MARK UKZ S 101800102 TO O 06778
	1929 W3	01	BENDIX -ENGINE REF MARK UKZ FROM O 06778
2	1920 C4	01	**SENSOR ENGINE** DIAM 12X150
3	1920 C5	01	**TEMPERAT PROBE**
4	5946 02	01	**PRESSURE SENSOR** AIR PRESSURE
5	5920 60	01	**SENSOR BRACKET**
6	5920 49	02	**PLASTIC NUT** 5X1,6
7	5953 06	01	**VACM UNIT UNION** CL 3,5X8-5X00
8	1920 C3	01	**SPEED SENSOR**
9	1920 E2	01	
10	6553 68	01	**ELECTRIC RELAY** 25 AMP LAMBDA PROBE
	1929 49	01	**RELAY** INJECTION - FUEL PUMP TO O 06566
	1920 3N	01	INJECTION - FUEL PUMP FROM O 06557
11	1628 1E	01	**POTENTIOMETER**
12	5946 15	01	**PINKING SENSOR** AV BE BLUE
	5946 16	01	AR BE BLUE
13	5918 85	01	**SPEED SENSOR** 2 VOIES
14	5918 84	01	**HOUSING**
30	6020 53	01	**SCREW** 6X100-25
31	6934 27	01	**WASHER-NUT** 6X100-6,25-10
32	6923 51	01	**SELF-TAP SCREWS** 5X80-30

.../...

31/08/2001

INJ CALCULATOR SENSOR



07/94 M1441200

M1441200

8		5920 49	02	**PLASTIC NUT** 5X1,6
9		5953 06	01	**VACM UNIT UNION** CL 3,5X8-5000
10		1920 C3	01	**SPEED SENSOR**
11		6355 68	01	**ELECTRIC RELAY** 25 AMP LAMBDA PROBE
				RELAY
		1929 49	01	INJECTION - FUEL PUMP TO O 06546
		1920 3N	01	INJECTION - FUEL PUMP FROM O 06547
12		5918 85	01	**SPEED SENSOR** 2 VOIES
13		5918 94	01	**HOUSING**
30		6920 53	03	**SCREW** 6X100-25
31		6934 27	03	**WASHER-NUT** 6X100-6,25-10
32		6923 51	02	**SELF-TAP SCREWS** 5X80-30
33	6935 31		02	*NUT WITH BASE 5X80-4,6-8*
	RP	6936 39	01	
34		6922 97	02	**SELF-TAP SCREWS** DIAM 6X100-20
35		6925 56	02	**SCREW WITH BASE** DIAM 6X125-27

31/08/2001

INJ CALCULATOR SENSOR



07/94 M1441200

M1441200

- INJECTION ZPJ

1	**1929 X**	01	**CALCULATOR** -BVM, ENGINE REF MARK UFY, ENGINE REF MARK UFZ, CODED IGNITION BENDIX S111700111 TO O 06778
	1929 1Q	01	BENDIX S111700111 -EEC 19-5 DEPOLL (ENGINE), BVM, ENGINE REF MARK UFY, ENGINE REF MARK UFZ: STANDARD IGNITION FROM O 06830 OR CODED IGNITION FROM O 06778
	1929 1S	01	BENDIX S111700112 -EEC 95 DEPOLL (ENGINE), BVM, ENGINE REF MARK UFZ FROM O 06779
	1929 1Y	01	-BVA, ENGINE REF MARK UFZ, CODED IGNITION BENDIX S111700211 TO O 06778
	1929 1R	01	BENDIX S111700211 -EEC 19-5 DEPOLL (ENGINE), BVA, ENGINE REF MARK UFZ: STANDARD IGNITION OR CODED IGNITION FROM O 06779
	1929 1T	01	BENDIX S111700212 -EEC 95 DEPOLL (ENGINE), BVA, ENGINE REF MARK UFZ FROM O 06779
2	**1628 1E**	01	**POTENTIOMETER**
3	**5946 15**	01	**PINKING SENSOR** AV BE BLUE
	5946 16	01	AR BE BLUE
4	**1920 C4**	01	**SENSOR ENGINE** DIAM 12X150
5	**1520 C5**	01	**TEMPERAT PROBE**
6	**5946 09**	01	**PRESSURE SENSOR** AIR PRESSURE
7	**5920 60**	01	**SENSOR BRACKET**

.../...

31/08/2001

INJ CALCULATOR SENSOR



M1441150

32	6922 97	01	**SELF-TAP SCREWS** DIAM 6X100-20
33	6921 83	01	**CAPSCREW** DIAM 8X125-35
34	6923 77	01	**SELF-TAP SCREWS** DIAM 6X100-16

31/08/2001

INJ CALCULATOR SENSOR



M1441150

- INJECTION XU10J4R

				CALCULATOR
1		1929 9L	01	-BVM, STANDARD IGNITION TO O 07146
		1929 9N	01	-BVM, CODED IGNITION TO O 06747
		1929 S3	01	-BVM, CODED IGNITION FROM O 06748 TO O 07146
		1929 Q2	01	-BVA, STANDARD IGNITION TO O 07146
		1929 Q4	01	-BVA, CODED IGNITION TO O 06747
		1929 9P	01	-BVA, CODED IGNITION TO O 07146
		1929 7E	01	FROM O 07147 TO O 07482
		1929 RV	01	FROM O 07483 TO O 07664
		1929 RW	01	FROM O 07665
				RELAY
2		1929 49	01	TO O 06565
		1920 3X	01	FROM O 06566
				SPEED SENSOR
3		1920 C3	01	TO O 06600
		1920 W9	01	FROM O 06601
4		1920 K9	C1	**SENSOR ENGINE** 12X1,50
				PRESSURE SENSOR
5		1920 V6	01	TO O 06747
		1920 Z2	01	FROM O 06748 TO O 07328
6		1920 9H	01	BOSCH FROM O 07329 TO O 08056
	1920 1K		01	*BOSCH*
	RP	1920 AN	01	*FROM O 08057*
7		5946 30	01	**PINKING SENSOR**
8		1628 1E	01	**POTENTIOMETER**
9		1920 T0	01	**TEMPERAT PROBE**
30		6925 53	04	**SCREW RLX** DIAM 6X100-20
31		6936 33	04	**NUT WITH BASE** DIAM 6X100-8-13

.../...

31/08/2001

INJ CALCULATOR SENSOR



M1441100

- TURBO INJECTION XU1\U2TE

1				**CALCULATOR**
		1929 X7	01	TO O 08747
		1929 AJ	01	FROM O 06748 TO O 07664
		1929 RX	01	FROM O 07665
				SPEED SENSOR
2		1920 C3	01	TO O 06628
		1920 W8	01	FROM O 06629
3		1957 46	01	**PAD CAPACITY**
4		1920 Q2	01	**SENSOR ENGINE** VE GREEN
				RELAY
5		1928 49	01	TO O 06600
		1920 3X	01	FROM O 06601
6		5953 06	02	**VACM UNIT UNION** CL 3,5X8-5000 01 FROM 6748 TO O 06747
7		5946 30	01	**PINKING SENSOR**
				POTENTIOMETER
8		1628 L1	01	TO O 06778
		1628 15	01	FROM O 06779
11		1920 T0	01	**TEMPERAT PROBE**
12		1622 E5	01	**VACUUM UNION** FROM O 08748
30		6922 97	01	**SELF-TAP SCREWS** DIAM.6X100-20
31		6925 53	04	**SCREW RLX** DIAM 6X100-20
32		6936 33	04	**NUT WITH RASE** DIAM 6X100-8-13
				CAPSCREW
33		6921 83	01	DIAM 8X125-35
34		6922 08	02	DIAM 4X70-16
35	*6981 80*		01	*HOSE CLIP DIAM 8-12 LARG 8*
	RP	6981 K6	01	